

PROVEN DESIGN PRODUCTS

Installation Instructions : Diamond Plate Trailer Mat

HARDWARE INCLUDED:

1 - Diamond Plate Trailer Mat
14 - Stainless Steel Black Screws

TOOLS REQUIRED:

- Power Screwdriver
- Phillips Head Bit

NOTE: Screws supplied are for mounting Diamond Plate Mat to wood decks, if mounting on another surface a pilot hole may be required.

STEP 1: Position Diamond Plate Mat on trailer deck where desired.

STEP 2: At one end of the Diamond Plate Mat place a screw in each corner 3/4" in from the edge, screw should slightly compress mat.

NOTE: It is best to install mat in temps around 70° and sunny to allow the mat to properly stretch. This helps with future buckling when the temperature drops.

STEP 3: At the other end, pull the Diamond Plate Mat tight and place screws in both corners 3/4" in from the edge like in step 2. At this point, you should have all 4 corners screwed down.

STEP 4: Space the remaining screws along the two long sides evenly.